

Set Rite

Oatey SCS (348)

Stop double stacking wax rings! Double stacking may lead to uneven compression, which could cause potential leak paths. Long term undetected leak paths would require costly water damage restoration. Use the Set-Rite® System instead for an air tight and leak free seal, every time! Set it once, set it rite with Set-Rite!

